



STL

The electronic speed controllers of the STL series control the speed of single phase (230 Vac - 50 Hz) voltage controllable motors by varying the supplied voltage through phase angle control.

There is a potentiometer and a separate ON/OFF switch with built in telltale, the minimum speed allowed can be adjusted internally with a little trimmer (factory preset = 100 V). The terminal board has a supplementary connection to bypass the ON/OFF switch (automatic start) or to branch off 230 V not controlled (three wire motor connection, valve, lamp, damper, etc ...).

There are two working modes, internally selectable by placing or removing the red jumper on the PCB.

 'Hard' start: The motor will always start (or restart) at max. speed for 8-10 seconds, after that the motor speed automatically follows the position of the potentiometer.
Normal start: the motor starts according to the position of the potentiometer.


The IP 54 case allows the use in demanding environments.

🗖 Features

- < Supply: 230 Vac 50 Hz
- < Infinitely variable control
- < Minimum speed adjustable by internal trimmer
- < Illuminated On/Off switch
- < Max ambient temperature: 35 °C
- < Plastic enclosure (R-ABS, UL94-V0, grey RAL 7035)
- < IP 54
- < According to the low voltage directive: 2006/95/EC / the EMC directive: 2004/108/EC

	STL-0-15-AT	STL-0-30-AT	STL-0-50-AT	STL-0-60-AT	STL-0100-AT
Current rating (A)	0,1 - 1,5	0,1 - 3,0	0,2 - 5,0	0,5 - 6,0	0,5 - 10,0
Fuse (A) 5*20 mm	F 2 A-H	F 5 A-H	F 8 A-H	F 8 A-H	F 16 A-H (6*32)

🗖 Wiring diagram



- 1. mains supply 230 Vac 50 Hz
- 2. fuse
- 3. output motor
- * 230 Vac not regulated output for connecting lamp, valve, dampers ... or three wire motor connection; branched off after switch and fuse

16/04/2009

* input: to bypass switch and fuse (ATTENTION) . jumper removed = normal working mode

- jumper in place = 'hard start' working mode
- minimum speed adjustment trimmer

🖸 Dimensions & fixing

